



Nr.	ASWO-Nº	Nr.	ASWO-Nº	Nr.	ASWO-Nº	Nr.	ASWO-Nº
1	*	14	FE	54	19 94 97	67	FE
2	*	15	FE	55	19 94 97	68	FE
3	*	16	FE	56	FE	69	FE
4	*	17	*	57	FE	81	FE
5	*	18	FE	58	FE	82	15 04 24
6	FE	19	FE	59	FE	83	FE
7	*	20	FE	60	FE	84	FE
8	FE	21	*	61	FE	85	FE
9	FE	22	*	62	FE	86	FE
10	FE	23	*	63	FE	88	FE
11	FE	51	FE	64	16 21 73	89	FE
12	FE	52	30 56 87	65	FE	90	FE
13	FE	53	20 64 22	66	23 12 03	91	FE




*) Diese Teile müssen gerätespezifisch bestellt werden, da sie teilweise unterschiedlich sind!
 These parts must be ordered by the specific model number, since they are not interchangeable!
 Ces pièces doivent être commandées par rapport au modèle, car elles diffèrent selon les versions!
 Questi pezzi devono essere ordinati secondo il tipo di apparecchio, perché parzialmente differenti!

Nr.	ASWO-N°	Nr.	ASWO-N°	Nr.	ASWO-N°	Nr.	ASWO-N°	Nr.	ASWO-N°
32	FE	154	FE	283	12 12 49	316	FE	347	FE
33	FE	155	FE	284	FE	317	FE	348	FE
34	FE	156	FE	285	16 45 21	318	FE	361	FE
35	FE	172	32 43 46	286	20 90 65	319	FE	362	FE
36	FE	173	9 07 67	287	23 12 03	320	FE	363	FE
37	FE	174	FE	288	106 17 58	321	FE	364	FE
38	FE	175	FE	289	FE	322	FE	365	FE
39	FE	176	FE	290	FE	331	FE	366	FE
40	FE	200	FE	291	49 40 95	332	FE	367	FE
41	33 39 83	202	FE	293	12 12 51	333	FE	368	FE
147	FE	203	FE	294	19 85 76	334	FE	369	FE
148	FE	204	FE	295	FE	335	FE	370	FE
149	FE	238	FE	296	FE	336	FE	371	FE
150	FE	241	FE	312	FE	337	FE	372	FE
151	FE	242	FE	313	FE	338	*	373	1 29 78
152	FE	281	*	314	FE	339	FE		
153	FE	282	FE	315	FE	346	FE		



*) Diese Teile müssen gerätespezifisch bestellt werden, da sie teilweise unterschiedlich sind!
 These parts must be ordered by the specific model number, since they are not interchangeable!
 Ces pièces doivent être commandées par rapport au modèle, car elles diffèrent selon les versions!
 Questi pezzi devono essere ordinati secondo il tipo di apparecchio, perché parzialmente differenti!

Nr.	ASWO-Nº	Nr.	ASWO-Nº	Nr.	ASWO-Nº	Nr.	ASWO-Nº
102	FE	142	FE	211	FE	255	FE
103	FE	143	FE	221	42 98 40	256	FE
104	FE	144	FE	222	FE	257	FE
105	FE	145	FE	223	FE	258	FE
121	FE	146	FE	224	FE	263	FE
122	FE	157	FE	226	FE	265	FE
131	28 21 43	171	*	234	FE	266	FE
132	FE	177	FE	235	41 06 69	267	FE
133	FE	178	FE	236	FE	268	FE
134	28 21 43	179	FE	237	FE	531	FE
135	FE	180	FE	238	FE	532	FE
136	FE	198	FE	239	38 29 44	533	FE
137	FE	205	FE	240	FE	534	FE
138	FE	206	FE	251	77 34 76	535	FE
139	FE	207	FE	252	FE	536	38 84 01
140	FE	209	FE	253	FE	537	23 12 03
141	FE	210	FE	254	FE	538	FE
						539	FE
						540	FE



*) Diese Teile müssen gerätespezifisch bestellt werden, da sie teilweise unterschiedlich sind!
 These parts must be ordered by the specific model number, since they are not interchangeable!
 Ces pièces doivent être commandées par rapport au modèle, car elles diffèrent selon les versions!
 Questi pezzi devono essere ordinati secondo il tipo di apparecchio, perché parzialmente differenti!